




Installing the conversion software

Please insert the installation CD into the PC, and follow the appropriate installation procedure. After the installation has been completed, make sure to restart the computer.



Converting the files into PPF format

Choose the file for conversion. Right click on the file, one of option displayed will show "Export for eFlash", click on it to begin conversion. For animation conversion, this function will work for PowerPoint and Macromedia Flash files only. Right click on the file, one of option displayed will show "Export for eFlash animation", click on it to begin conversion.

Transfer file into eFlash

After conversion process has completed, a folder will appear, which displays "My eFlash Presentation" and it will contain the converted file and the original file. Please drag the files into the desired flash card.

Then you are ready to go and do presentation!

The logo for e|flash, with the word 'e|flash' in a lowercase, sans-serif font, where the vertical bar is positioned between the 'e' and 'flash'.

