



Remove dust



Spray evenly



Wipe clean



Instruction

1 Use provided anti-static brush to brush off the dust particles on the screen – if dirt still remains on the screen, follow step two **2** Use provided cleaning fluid, spray on screen at 15cm distance; 2 to 3 sprays are enough to clean the whole screen **3** Then use the flat screen cleaner to clean off the screen **4** To clean all corners of the screen, use the triangular ends of the cleaner to pick-out the dusts **5** Place the flat screen cleaner back to the provided bracket after use **6** We recommend user to clean screen at least once every two weeks to maintain optimal viewing experience.

Precaution

- Please refrain from spraying too much cleaning fluid as this may cause dripping.
- Refrain from exerting excess force on the screen during cleaning, as this may cause damage to the screen.
- Do not point the spray at any human eyes – consult doctor immediately in case of eye contact with the spray.
- Do not point the triangular ends of the flat screen cleaner directly at any screens as this may cause damage to the screens.
- Keep out of reach of children.

Then you are ready to view the screen like it was new!